

Contents

SECTION 1 Related Processes 00

Chapter 1 Introduction to Pipe Welding 00

Objectives	00
Key Terms	00
Introduction	00
Piping Systems	00
Pipe Applications	00
How Pipe is made	00
Pipe vs Round Tubing	00
Pipe Standards	00
Pipe Specifications	00
Pipe Dimensioning	00
Round Tubing Specifications	00
Tubing Dimensions	00
Pressure and Strength Ranges	00
Pipe Systems Codes and Standards	00
Pipe Welding Processes	00
Types of Pipe Welding Jobs	00
Manufacturing Pipe Welding Jobs	00
Construction Pipe Welding Jobs	00
Pipeline Welding Jobs	00
Teamwork	00
Leadership	00
Metric Units	00
Summaryv	00
Review	00

Chapter 2 Welding Safety 00

Objectives	00
Key Terms	00
Introduction	00
Piping Systems	00
Pipe Applications	00
How Pipe is made	00
Pipe vs Round Tubing	00

Pipe Standards	00
Pipe Specifications	00
Pipe Dimensioning	00
Round Tubing Specifications	00
Tubing Dimensions	00
Pressure and Strength Ranges	00
Pipe Systems Codes and Standards	00
Pipe Welding Processes	00
Types of Pipe Welding Jobs	00
Manufacturing Pipe Welding Jobs	00
Construction Pipe Welding Jobs	00
Pipeline Welding Jobs	00
Teamwork	00
Leadership	00
Metric Units	00
Summaryv	00
Review	00

Chapter 3 Shop Math 00

Objectives	00
Key Terms	00
Introduction	00
Piping Systems	00
Pipe Applications	00
How Pipe is made	00
Pipe vs Round Tubing	00
Pipe Standards	00
Pipe Specifications	00
Pipe Dimensioning	00
Round Tubing Specifications	00
Tubing Dimensions	00
Pressure and Strength Ranges	00
Pipe Systems Codes and Standards	00
Pipe Welding Processes	00
Types of Pipe Welding Jobs	00
Manufacturing Pipe Welding Jobs	00



Preface

Introduction

The welding industry presents a continuously growing and changing series of opportunities for skilled welders. Even with economic fluctuations, the job outlook for skilled welders is positive. Due to a steady growth in the demand for goods fabricated by welding, new welders are needed in every area of welding such as small shops, specialty fabrication shops, large industries, and construction. The student who is preparing for a career in welding will need to

- have excellent eye–hand coordination.
- work well with tools and equipment.
- know the theory and application of the various welding and cutting processes.
- be able to follow written and verbal instructions.
- work with or without close supervision.
- have effective written and verbal communications skills.
- be able to resolve basic mathematical problems.
- work well individually and in groups.
- read and interpret welding drawings and sketches.
- be computer literate.
- be alert and work safely.

A thorough study of *Welding: Principles and Applications* in a classroom/shop setting will help students prepare for the opportunities in welding technology. The comprehensive technical content provides the basis for the welding processes. The extensive descriptions of equipment and supplies, with in-depth explanations of their operation and function, are designed to familiarize students with the tools of the trade. The process descriptions, practices, and experiments coupled with actual performance teach the critical fabrication and welding skills required on the job. The text also discusses occupational opportunities in welding and explains the training required for certain welding occupations. The skills and personal traits recommended by the American Welding Society (AWS) for its Certified Welder program are included within the text. Students wishing to become certified under the AWS program must contact the American Welding Society for specific details.

The National Center for Welding Education and Training, known as Weld-Ed, is a partnership between business and industry, community and technical colleges, universities, the American Welding Society, and government to promote welding education.

A thorough study of *Welding: Principles and Applications* in a classroom/shop setting will help students prepare for the opportunities in welding technology. The comprehensive technical content provides the basis for the welding processes. The extensive descriptions of equipment and supplies, with in-depth explanations of their operation and function, are designed to familiarize students with the tools of the trade. The process descriptions, practices, and experiments coupled with actual performance teach the critical fabrication and welding skills required on the job. The text also discusses occupational opportunities in welding and explains the training required for certain welding occupations. The skills and personal traits recommended by the American Welding Society (AWS) for its Certified Welder program are included within the text. Students wishing to become certified under the AWS program must contact the American Welding Society for specific details.

The National Center for Welding Education and Training, known as Weld-Ed, is a partnership between business and industry, community and technical colleges, universities, the American Welding Society, and government to promote welding education.

The welding industry presents a continuously growing and changing series of opportunities for skilled welders. Even with economic fluctuations, the job outlook for skilled welders is positive. Due to a steady growth in the demand for goods fabricated by welding, new welders are needed in every area of welding such as small shops, specialty fabrication shops, large industries, and construction. The student who is preparing for a career in welding.

The text also discusses occupational opportunities in welding and explains the training required for certain welding occupations. The skills and personal traits recommended by the American Welding Society (AWS) for its Certified Welder program are included within the text. Students wishing to become certified under the AWS program must contact the American Welding Society for specific details.

Section 5

Related Processes

Chapter 18

Shop Math and Weld Cost

Chapter 19

Reading Technical Drawings

Chapter 20

Welding Joint Design and Welding Symbols

Chapter 21

Fabricating Techniques and Practices

Chapter 22

Welding Codes and Standards

Chapter 23

Testing and Inspection of Welds

Chapter 24

Welder Certification



Chapter 32

Oxyacetylene Welding

OBJECTIVES

After completing this chapter, the student should be able to

- explain how to set up and weld mild steel.
- make a variety of welded joints in any position on thin-gauge, mild steel sheet.
- make a satisfactory weld on small diameter pipe and tubing in any position.
- explain the effects of torch angle, flame height, filler metal size, and welding speed on gas welds.

KEY TERMS

1G position

2G position

5G position

6G position

burnthrough

flashing

flat butt joint

heat sink

horizontal welds

keyhole

kindling point

lap joint

molten weld pool

out-of-position welding

outside corner joint

overhead weld

overlap

penetration

shelf

tee joint

torch angle

torch manipulation

trailing edge

undercut

vertical weld

weld crater

INTRODUCTION

Oxyacetylene welding is limited to thin metal sections or to times when portability is important. During the early years of welding, oxyacetylene was used to weld thick plate, 1 in. (25 mm) and thicker. Today, it is used almost exclusively on thin metal, 11 gauge or thinner. One of the arc welding processes is most often used today for welding metal thicker than 16 gauge. Some of the arc welding processes, such as GMAW, are replacing the gas welding processes on metals as thin as 28 gauge, Figure 32-1. Because of the expanded use of arc welding processes on thinner sections, we will concentrate on the use of gas welding on metal having a thickness of 16 gauge (approximately 1/16 in. [2 mm]) or thinner.

MILD STEEL WELDS

Mild steel is the easiest metal to gas weld. With this metal, it is possible to make welds with 100% integrity (lack of porosity, oxides, or other defects) and that have excellent strength, good ductility, and other positive characteristics. The secondary flame shields the molten weld pool from the air, which would cause oxidation. The atmospheric oxygen combines with the carbon monoxide (CO) from the outer flame envelope to produce carbon dioxide (CO₂). The carbon dioxide will not react with the molten weld pool. In addition, the carbon dioxide forces the surrounding atmosphere away from the weld.

Abbreviations for Units				
Units	Standard		Metric	
Temperature	F	Fahrenheit	C	Celsius
Length	yd	yard	m	meter
	ft	feet	cm	centimeter
	in.	inches	mm	millimeter
Weight	lb	pounds	kg	kilogram
	oz	ounces	g	grams
Liquid	gal	gallons	L	liters
	qt	quarts		
	pt	pints		
	oz	ounces		
Pressure	psi	pounds per square in.	kPa	kilopascal

TABLE 18-1 Common Abbreviations for Units of Measure

Factors Affecting the Weld

Torch Tip Size The torch tip size should be used to control the weld bead width, penetration, and speed. **Penetration** is the depth into the base metal that the weld fusion or melting extends from the surface, excluding any reinforcement. Because each tip size has a limited operating range in which it can be used, tip sizes must be changed to suit the thickness and size of the metal being welded. Never lower the size of the torch flame when the correct tip size is unavailable. If the flame size or volume is lowered below the correct size by lowering the gas flow, the tip will overheat. If the flame is lowered significantly, the tip can overheat even without using it to weld. Overheated tips will backfire. Backfiring can cause dangerous flashback.

Other factors that can be changed to control the weld size are the torch angle, the flame-to-metal distance, the welding rod size, and the way the torch is manipulated.

1. have excellent eye–hand coordination.
2. work well with tools and equipment.
3. know the theory and application of the various welding and cutting processes.
4. be able to follow written and verbal instructions.

CAUTION

It is never safe to lower the flame size if the tip's flame produces too much heat for your welding job. Get a smaller tip or change your welding technique.

Torch Angle The torch angle and the angle between the inner cone and the metal have a great effect on the speed of melting and size of the molten weld pool. The ideal angle for the welding torch is 45°. As this angle increases toward 90°, the rate of heating increases. As the angle decreases toward 0° to the plate's surface, the rate of heating decreases, as illustrated in **Figure 32-2**. The distance between the inner cone and the metal ideally should be 1/8 in. to 1/4 in. (3 mm to 6 mm). As this distance increases, the rate of heating decreases; as the distance decreases, the heating rate increases, **Figure 32-3**.

Welding Rod Size Welding rod size and torch manipulation can be used to control the weld bead characteristics. A larger welding rod can be used to cool the molten weld pool, increase buildup, and reduce penetration, **Figure 32-4A, B, and C**. The torch can be manipulated so that the direct heat from the flame is flashed off the molten weld pool for a moment to allow it to cool, **Figure 32-5**.

CHARACTERISTICS OF THE WELD

The molten weld pool must be protected by the secondary flame to prevent the atmosphere from contaminating the metal. If the secondary flame is suddenly moved away from a molten weld pool, the pool will throw off a large number of sparks. These sparks are caused by the rapid burning of the metal and its alloys as they come into contact with oxygen in the air. This is particularly a problem when a weld is stopped. The weld crater is especially susceptible to cracking. This tendency is greatly increased if the molten weld pool is allowed to burn out, **Figure 32-6**.

To prevent burnout,

- have excellent eye–hand coordination.
- work well with tools and equipment.
- know the theory and application of the various welding and cutting processes.
- be able to follow written and verbal instructions.

The sparks that occur as the weld progresses are due to metal components that are being burned out of the weldment. Silicon oxides make up most of the sparks, and extra silicon can be added by the filler metal so that the weldment retains its desired soundness. A change in the number of sparks given off by the weld as it progresses can be used as an indication of changes in weld temperature.

An increase in sparks on clean metal means an increase in weld temperature. A decrease in sparks indicates a decrease in weld temperature. Often the number of sparks in the air increases just before a burnthrough takes place—that is, burning out the molten metal that appears on the back side of the plate. This burnout does not happen to molten metal until it reaches the kindling point (the temperature that must be attained before something begins to burn). Small amounts of total penetration usually will not cause a burnout. When the sparks increase quickly, the torch should be pulled back to allow the metal to cool and prevent a burnthrough.

THINK GREEN

Conserve Filler Metal

The short ends of both welding and brazing rods can be fused together so that the amount of scrap filler metal can be minimized, unlike most other filler metal such as SMAW, GMAW, and FCAW. Being able to use all of the filler metal can be a significant saving of shop funds and reduces waste materials.

EXPERIMENT 32-1

Flame Effect on Metal

The first experiment examines how the flame affects mild steel. Use a piece of 16-gauge mild steel and the proper-size torch tip. Light and adjust the flame by turning down the oxygen so that the flame has excessive acetylene. Hold the flame on the metal until it melts and observe what happens, Figure 32-7. Now adjust the flame by turning up the oxygen so that the flame is neutral. Hold this flame on the metal until it melts and observe what takes place, Figure 32-8. Next, adjust the flame by turning up the oxygen so that the flame has excessive oxygen. Hold this flame on the metal until it melts and observe what happens, Figure




FIGURE 32-25 The keyhole in the root of the joint helps to ensure 100% root penetration. © Cengage Learning 2012

32-9. Repeat this experiment until you can easily identify each of the three flame settings by the flame, molten weld

pool, sound, and sparks.

Before actual welding is started, it is a good idea to find a comfortable position. The more comfortable or relaxed you are, the easier it will be for you to make uniform welds. The angle of the plate to you and the direction of travel are important.

Place a plate on the table in front of you and, with the torch off, practice moving the torch in one of the suggested patterns along a straight line, as illustrated in Figure 32-10. Turn the plate and repeat this step until you determine the most comfortable direction of travel. Later, when you have mastered several joints, you should change this angle and try to weld in a less comfortable position. Welding in the field or shop must often be done in positions that are less than comfortable, so the welder needs to be somewhat versatile.

It is important to feed the welding wire into the molten weld pool at a uniform rate. Figure 32-11A and B show some suggested methods of feeding the wire by hand. It is also suggested that you not cut the welding wire into two pieces for welding. Short lengths are easy to use, but this practice often results in wasted filler metal. The end of the welding wire may be rested on your shoulder so that it is easy to handle. ♦

NOTE

Being able to use all of the filler metal can be a significant saving of shop funds and reduces waste materials. It is never safe to lower the flame size if the tip's flame produces too much heat for your welding job. Get a smaller tip or change your welding technique.

PRACTICE 32-2

Beading

Repeat Experiment 32-2 until you can control the change in the size of the molten weld pool, as shown in Figure 32-17. After the control of the molten weld pool has been mastered, you are ready to start adding filler rod. When selecting and adding filler metal, the following are some facts to remember.

Selecting the proper size or correct diameter of filler metal will help control the weld bead width, buildup, and penetration. A large diameter filler rod can be used as a heat sink (something to draw off excessive heat) to keep the molten weld pool narrow, with little penetration and high buildup. As the diameter of the filler wire is decreased, the heat-absorbing effect decreases, and the molten weld pool becomes wider, with deeper penetration and reduced buildup. On thin metal. Another thing to remember when adding filler metal to a weld is to keep a smooth. ♦

Summary

In an ideal world we would all have the correct tip size for every job we attempted; however, in reality often the oxyfuel welding process is used for repair work when it is not possible to have an infinite selection of tip sizes. Learning to control the heat input to the weld by changing the torch angle, height, or travel speed is important so that you can produce satisfactory welds under these service conditions. It is not safe or recommended that you turn down the flame below the tip's optimal operating capacity. Therefore, you must learn to control the heat by changing the angle, tip height, or travel speed.

Oxyacetylene welding is the process of preference for part-time and amateur welders. It allows them the greatest flexibility and is often the most forgiving. The most common problem OF welding presents is heat and weld distortion on large weldments. Because of the difficulty in controlling distortion and the time required to make large welds, other welding processes are often selected for such welds. That is not to say that large welds are not possible with OF welding; they just take more time and skill.

Confined Space Monitors: Tough Choices for Tight Spots



Reliable operation and proper features in a gas monitor are a must if you are working in a confined space.

Confined space—just the sound of it appears challenging to those who are even slightly claustrophobic. Read the Occupational Safety and Health Administration's (OSHA's) definition of a permit-required confined space—. . . an area with limited or restricted means of entry and exit: not designed for continuous human occupancy; potential to contain a hazardous atmosphere"—and it is apparent that these areas are somewhat less than desirable places to spend the workday. Unfortunately for many, entry and work in confined spaces are a fact of everyday work life.

Confined spaces exist in almost every industry and in every workplace. If you are an electrician, a plumber, a pipe fitter, a welder, a boiler maker, a carpenter, or an emergency service worker, chances are that at some point your daily duties will require you to enter a confined space and be challenged by the hazards that await there.

Know the Hazards

Some of the hazards in confined spaces are easily recognized. It can be relatively easy to see the potential for falls or entrapment from cave-ins or falling equipment. However, it is the unseen atmospheric hazards that present the greatest danger in a confined space. The lack of breathable oxygen, the potential for explosion due to dangerous levels of combustible gases, or the presence of deadly poisonous gas vapors, such as carbon monoxide, cannot be seen. Therefore, you must rely on the readings of a portable gas-monitoring instrument to alert you of potential danger.

Before you drop down a manhole or crawl into a tank car, following are some considerations concerning the gas monitor you choose and the procedures you follow to ensure your safety.

Choosing the Right Sensor

Make sure the sensors in the instrument you are using are appropriate for the confined space. Many people consider a confined space monitor to be the same as a four-gas instrument containing sensors for oxygen, combustible gas, carbon monoxide, and hydrogen sulfide. Although it is true that most confined spaces potentially contain some hazards related to one of these gases, it is not true for all. If you are entering a space that may contain chlorine, an instrument with carbon monoxide and hydrogen sulfide sensors is of little use. Many instruments offer you the ability to change the sensors to match the hazard you will encounter. These instruments provide greater flexibility and value in a wide variety of applications.

A gas-monitoring instrument must be durable and able to withstand harsh conditions. Although a portable gas detector is certainly a sophisticated piece of electronic.

Working in confined spaces poses potential hazards that require special precautions. American Welding Society equipment, it is still a tool. As such, it is subjected to the rigors of the environment it is used in, just as is any other tool. It is dropped, dunked, or caught up in other equipment, and all the while it must still provide a potentially life-saving service. Be certain the instrument you choose is constructed in a manner that will not let its, or your, survival in a tough environment be left to chance.

Confined space preentry tests require remote sampling of the atmosphere from outside the space. Therefore, the instrument you choose must have the capability of using a remote sample pump. The pump must be able to draw an adequate sample flow over the distance required to cover the entire space. The pump also should be able to detect and clearly inform you if the sample line



FIGURE 32-1 Gas metal arc welded (GMAW) on 16-gauge mild steel. Larry Jeffus

is blocked, thereby preventing gas flow to the instrument and its sensors.

Be certain that the sample tube material you are using with the pump is of high quality and is compatible with the vapors that you expect to encounter. Some highly reactive gases, such as chlorine, nitrogen dioxide, and hydrogen chloride, may be absorbed into the walls of the tubing and scrubbed from the sample stream. Never use sample tubing made of materials containing silicone rubber compounds. The silicone vapors may off-gas from the tubing and poison catalytic bead-type combustible gas sensors, leaving the instrument unable to detect explosive gases. Sample tubing made of urethane or FEP (Teflon) is generally suitable for most applications.

Check the Power

A gas monitor should be able to operate from a variety of power supplies. Rechargeable batteries are generally best for portable monitoring instruments because the combustible gas sensors used in the detectors consume large amounts of battery power. Extended confined space operations often require instrument run times beyond the capacity of the rechargeable batteries. The ability to replace the rechargeable battery pack with disposable alkaline or lithium battery cells will certainly come in handy in these situations. In addition, make sure that the instrument is capable of running the required amount of time when the sample pump is being used. Some sample pumps use the instrument's battery for power and reduce the run time of the instrument much more than you might expect.

Know the detection limits of the instrument. There are clear differences in the measuring ranges of sensors in various instruments. As a rule of thumb, the monitor should be capable of measuring concentrations approaching the immediately dangerous to life and health (IDLH) level of the target gas. All catalytic combustible gas sensors require a minimum background oxygen concentration be present to respond accurately. Be aware of what that level is and make sure the instrument you choose can be used with

a dilution apparatus. By doing so, you will ensure the accuracy of the combustible detector when sampling from an inert or oxygen-deficient atmosphere.

Calibrate Often

Beware of claims that instruments do not need to be tested or calibrated on a regular basis. Know one thing for sure: the only way to ensure a gas monitor will respond to gas is to test and verify its operation with known concentrations of the target gases prior to each use. For example, someone using the instrument before you might have damaged one of the sensors, resulting in no difference in the response of a catalytic or an electrochemical gas sensor used in a clean atmosphere from one that has failed catastrophically. Regular calibration and functional testing will guarantee that the instrument and its sensors are working properly. Whether or not it is done is up to you. If calibration and testing are too difficult and cumbersome for you to do on your own, docking systems and service programs are available to perform these tasks automatically on your instruments and to document the results.

Keep Monitoring

Whether to monitor continuously or not is an often-asked question. Usually, confined space atmospheres are tested before entry to complete the required permits, and then the gas monitor is put back on the truck until the next test. Unfortunately, the work done while in the confined space may create an unseen hazard. Chemical reactions with solvents during cleaning processes in tanks or vapors produced during maintenance operations, such as welding, can build up dangerous gases in a confined space while you work. Continuous monitoring of the space's atmosphere during the entire entry will ensure there is no danger.

An instrument capable of activating a remote alarm will also alert your partner watching from outside to hazardous conditions.

There are so many choices and so little room for error. Make sure you take time to know and understand the hazards of confined space operations and ensure you have the right equipment. It could save your life.

Article courtesy of the American Welding Society.

Glossary

The terms and definitions in this glossary are extracted from the American Welding Society publication AWS A3.0-80 Welding Terms and Definitions. The terms with an asterisk are from a source other than the American Welding Society. Note: The English term and definition are given first, followed by the same term and definition in Spanish.

A

***abrasives.** Materials that are usually sharp and are used to clean or grind a surface. They may be used as a powder such as sand to blast the surface or they may be formed into disks or stones to be used by a grinder.

abrasivos. Materiales que son por lo general ásperos y que se utilizan para limpiar o pulir superficies. Pueden venir en polvo, como arena, para bruñir las superficies, o en forma de discos o piedras para ser usados por una esmeriladora.

***absolute pressure.** The sum of the gauge pressure and the atmospheric pressure.

presión absoluta. La suma de la presión manómetro y la presión atmosférica.

absorptive lens. A filter lens designed to attenuate the effects of transmitted and reflected light.

lente absorbente. Un lente de filtro diseñado para disminuir los efectos de la luz y la reflexión de la luz extraviada.

acceptable criteria. Agreed upon standards that must be satisfactorily met.

critérios aceptables. Las normas sobre las que se ha llegado a un acuerdo y que deben cumplirse en forma satisfactoria.

acceptable weld. A weld that meets all the requirements and the acceptance criteria.

soldadura aceptable. Una soldadura que satisface los requisitos y el criterio aceptable prescrita por las especificaciones de la soldadura.

***acetone.** A fragrant liquid chemical used in acetylene cylinders. The cylinder is filled with a porous material and acetone is then added to fill. Acetylene is then added and absorbed by the acetone, which can absorb up to 28 times its own volume of the gas. **acetona.** Un líquido fragante químico que se usa en los cilindros del acetileno. El cilindro se llena de un material poroso y luego se le agrega la acetona hasta que se llene. El acetileno es absorbido por la acetona, la cual puede absorber 28 veces el propio volumen del gas.

***acetylene.** A fuel gas used for welding and cutting. It is produced as a result of the chemical reaction between calcium carbide and water. The chemical formula for acetylene is C₂H₂. It is colorless, is lighter than air, and has a strong garlic-like smell. Acetylene is unstable above pressures of 15 psig (1.05 kg/cm² g). When burned in the presence of oxygen, acetylene produces one of the highest flame temperatures available.

acetileno. Un gas combustible que se usa para soldar y cortar. Es producido a consecuencia de una reacción química de agua y

B

calcio y carburo. La fórmula química para el acetileno es C₂H₂. No tiene color, es más ligero que el aire, y tiene un olor fuerte como a ajo. El acetileno es inestable en presiones más altas de 15 psig (1.05 kg/cm² g). Cuando se quema en presencia del oxígeno, el acetileno produce una de las llamas con una temperatura más alta que la que se utiliza.

***acicular structure.** A fine micrograin structure found in rapidly cooled steel.

***estructura acicular.** Una estructura micro granulada fina que se encuentra en el acero que se ha enfriado con rapidez.

actual throat. See throat of a fillet weld.

garganta actual. Vea garganta de soldadura filete.

***adaptable.** Capable of making self-directed corrections; in a robot, this is often accomplished with visual, force, or tactile sensors. **adaptable.** Capaz de hacer correcciones por

***absolute pressure.** The sum of the gauge pressure and the atmospheric pressure.

presión absoluta. La suma de la presión manómetro y la presión atmosférica.

absorptive lens. A filter lens designed to attenuate the effects of transmitted and reflected light.

lente absorbente. Un lente de filtro diseñado para disminuir los efectos de la luz y la reflexión de la luz extraviada.

acceptable criteria. Agreed upon standards that must be satisfactorily met.

critérios aceptables. Las normas sobre las que se ha llegado a un acuerdo y que deben cumplirse en forma satisfactoria.

acceptable weld. A weld that meets all the requirements and the acceptance criteria.

soldadura aceptable. Una soldadura que satisface los requisitos y el criterio aceptable prescrita por las especificaciones.

***absolute pressure.** The sum of the gauge pressure and the atmospheric pressure.

presión absoluta. La suma de la presión manómetro y la presión atmosférica.

absorptive lens. A filter lens designed to attenuate the effects of transmitted and reflected light.

lente absorbente. Un lente de filtro diseñado para disminuir los efectos de la luz y la reflexión de la luz extraviada.

acceptable criteria. Agreed upon standards that must be sa-

Index

A

AAR. See Association of American Railroads
AASHTO. See Association of American of State Highway and Transportation Officials
Abbreviations, 19t
Abrasives, 227
Absolute pressure, 759
AC. See Alternating current
Acetone, 35, 786
Acetylene (C₂H₂), 786–788, 786f–788f, 787t
 cylinders, 35, 36f
 for flame cutting, 161t
Acicular structure, needle-like, 654, 654f
Adjustable wrench, 38, 38f
Advanced shielded metal arc welding, 128–156.
 See also Shielded metal arc welding cover pass in, 138–139, 138f–139f
 filler pass in, 136–138, 137f–138f
 hot pass in, 134–136, 135f–136f
 introduction to, 129
 plate preparation in, 139, 140f, 141, 141f
 poor fit-up in, 152–154, 153f
 postheating in, 144, 152 preheating, 144, 144t
 preparing specimens for testing in, 141–142, 141f–142f
 restarting a weld bead in, 142–144, 143f–144f, 600–601, 600f–601f
 root pass in, 129–134, 129f–134f, 134t
Aerospace Industries Association (AIA), 551
AIA. See Aerospace Industries Association
Air carbon arc cutting (CAC-A), 11, 219, 219f, 220t
 applications of, 221–222, 222f–223f
 electrodes in, 220–221, 221f
 equipment and, 223
 gouging in, 222, 222f
 safety in, 222–223
 washing in, 222, 223f
Air Conditioning National Contractors Association, 547
Air-cooled welding guns, 299–300, 300f
Air Force, 478–479
Airports, 358–359
Air supply, 221
AISI. See American Iron and Steel Institute
Al-2, 704
Al-43, 704
Allen, Jim, 103–104
Allotropic metal, 647
Allotropic transformation, 660
Alloying elements, 304, 698t
Alloys. See also specific alloys
 not specified EWG electrode, 377
 steels, 670t, 671–674
 low, 674
All-position welding, 301
Alphabet of lines, 482, 484t, 485f
Alternate bend test, 580
Alternating current (AC), 57, 58f
Alternators, 63–64, 64f
Aluminum, 220t, 405–406, 405f, 670t, 691 filler metal for, 405t
 filler metal selection with, 704, 705t weldability of, 681–682
Aluminum bare welding rods and electrodes, 704

Aluminum-covered arc welding electrodes, 704
Aluminum-silicon, 843
American Bureau of Shipping, 103, 141, 568t
American Iron and Steel Institute (AISI), 370 classification system of, 671, 672t
American Museum of Natural History, 394–396
American National Standards Institute (ANSI), 47, 551
American Petroleum Institute (API), 551, 568t
American Railway Engineering and Maintenance-of-Way Association (AREMA), 551
American Society for Testing and Materials, 568t
American Society of Mechanical Engineers (ASME), 141, 568t
ASME Section IX, 551, 555
American Water Works Association (AWWA), 551
American Welding Society (AWS), 5, 129, 141, 259, 568t
AWS A5.01-93 document of, 707–708
AWS A5.32, 796–797
AWS D1.1, 551, 555
filler metal selection classifications of, 696, 697t welder certification levels of, 15
Ammonium persulphate, 582
Amperage, 244, 336–337 of current, 56
 in plasma arc cutting, 196 range, 75, 75f, 77, 337
Annealing, 652, 658, 658f
ANSI. See American National Standards Institute
Antarctica, 20–21
 API. See American Petroleum Institute
 API Standard 1104, 551
 Apollo-5, 478, 519
 Ar. See Argon
 Arc blow, 59, 59f–60f
 Arc cutting, 192
 Arc cutting electrodes, 227, 228, 228f
 Arc length, 77–78, 77f–78f
Arc plasma, 192
Arc stabilizers, 304
Arc starting methods, 365, 365f
Arc strikes, 572, 572f
Arc-voltage and amperage characteristics, GMAW, 270–271, 271t
Arc welding, 746–747
 thermal effects of, 658–660, 659f–660f

B

AREMA. See American Railway Engineering and Maintenance-of-Way Association
Argon (Ar), 202t, 235, 243, 247, 249, 275t conserving, 389
 in GTAW, 387, 387f Arm protection, 34, 34f Arrows, 484, 484t
 weld joint design and location significance of, 512
Artists, 155–156
AS-203 mission, 478
ASME. See American Society of Mechanical Engineers
ASME Section IX, 551, 555
Assembly, 522
 fabrication and, 537–539, 537f–539f tools for, 539–541, 540f–541f
Association of American of State Highway and Transportation Officials (AASHTO), 551
Association of American Railroads (AAR), 551
Atmospheric pressure, 759
Atomic hydrogen, 706
Atoms, 783

Appendix



- I.** Student Welding Report
- II.** Conversion of Decimal Inches to Millimeters and Fractional Inches to Decimal-Inches and Millimeters
- III.** Conversion Factors: U.S. Customary (Standard) Units and Metric Units (SI)
- IV.** Abbreviations and Symbols
- V.** Metric Conversion Approximations
- VI.** Pressure Conversion
- VII.** Welding Codes and Specifications
- VIII.** Welding Associations and Organizations